



Canon PowerShot A630 Zoom Lens Ring Replacement

Damage to the zoom lens ring may affect the ability of the zoom lens to extend and retract. This guide will show you how to replace your zoom lens ring if it is damaged.

Written By: Alicia Burns



Step 1 — Zoom Lens Ring



- Press down on the indicated button.
- While still pressing down on the button, grip the edges of the zoom lens ring and turn counterclockwise.

Step 2



- Lift the zoom lens ring to remove it.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-18 07:02:14 PM.